

Accessory Compatibility Chart

Accessories	Hero4 Black	Hero4 Silver	Hero 3+ Silver	Hero3 White	Hero
LCD Touch BacPac (3rd generation)	X	X	X	X	
Battery BacPac (3rd generation)	X	X	X	X	
Smart Remote	X	X	X (Settings/Tag Button not compatible)	X (Settings/Tag Button not compatible)	
The Tool	X	X	X	X	X
Floaty Backdoor	X	X	X	X	X
Anti-Fog Inserts	X	X	X	X	
Standard Housing	X	X	X	X	
Skeleton Housing	X	X	X	X	
Blackout Housing	X	X	X	X	
Dive Housing	X	X	X	X	
Protective Lens + Covers	X	X	X	X	
Protective Lens	X	X	X	X	
Lens Replacement Kit (for Standard, Skeleton + Blackout housing)	X	X	X	X	
Lens Replacement Kit (For Dive + Wrist Housing)	X (Requires Dive or Wrist Housing)	X (Requires Dive or Wrist Housing)	X (Requires Dive or Wrist Housing)	X (Requires Dive or Wrist Housing)	
BacPac Backdoor kit (for Standard + Skeleton Housing)	X	X			
Magenta Dive Filter (For Standard + Blackout Housing)	X	X			X
Red Dive Filter (For Standard + Blackout Housing)	X	X			X
Magenta Dive Filter (For Dive + Wrist Housing)	X (Requires Dive or Wrist Housing)	X (Requires Dive or Wrist Housing)	X (Requires Dive or Wrist Housing)	X (Requires Dive or Wrist Housing)	
Red Dive Filter (For Dive + Wrist Housing)	X (Requires Dive or Wrist Housing)	X (Requires Dive or Wrist Housing)	X (Requires Dive or Wrist Housing)	X (Requires Dive or Wrist Housing)	
Camera Tethers	X	X	X	X	X
Accessory Kit (for Smart Remote + Wi-Fi Remote)	X	X	X	X	
Attachment Keys + Rings (For Smart Remote + Wi-Fi Remote)	X	X	X	X	
Bag Pack (5 pack)	X	X	X	X	X
Dual Battery Charger (For HERO4)	X	X			
Dual Battery Charger (For HERO3+, HERO3)			X	X	
Auto Charger	X	X	X	X	X
Wall Charger	X	X	X	X	X
Rechargeable Battery (For HERO4)	X	X			
Rechargeable Battery (For HERO3+, HERO3)			X	X	
3.5mm Mic Adapter	X	X	X	X	
Combo Cable	X	X	X	X	
Mini USB Composite Cable	X	X	X	X	
Charging Cable (For Smart Remote + Wi-Fi Remote)	X	X	X	X	
Lexar 32/64 GB SD Card	X	X	X	X	X (32GB only)
SanDisk 32/64 GB SD Card	X	X	X	X	X (32GB only)